


Casio Piano KeyBoard Scan



Port 2					Port 1								
0	1	2	4	4	7	6	5	4	3	2	1	0	
1	2	3	4	5	6	7	8	9	10	11	12	13	

2	4	6	8	10	12	14
1	3	5	7	9	11	13

Note:Keyboard cable modified to be a 14 pin ribbon cable.

