



# IHLP Selection Example

## INPUT

L <sub>REQ</sub>	I <sub>DC</sub>	ΔI	Freq.	T <sub>AMB</sub>	V-μs	δ
0.54 μH	20 A	7.39 A	300 kHz	50 °C	4.14	0.46

## IHLP SELECTED

### Step 1.

IHLP-4040DZ-01 0.56 μH								
L	DCR	I <sub>HEAT</sub>	I <sub>SAT</sub>	R <sub>TH</sub>	P <sub>HEAT</sub>	ET <sub>100</sub>	K <sub>0</sub>	K <sub>1</sub>
0.56 μH	0.0018 Ω	30 A	49 A	26.96 °C/W	1.48 W	0.88	18.31	0.00340

## VERIFICATION

### Step 2.

$$B_{PK_{OPER}} = \frac{4.14}{0.88} \times 100 = 470.5 \text{ G}$$

### Step 3.

$$f_e = \frac{300\,000}{2\pi(0.46 - 0.46^2)} = 192\,216.1 \text{ Hz}$$

### Step 4.

$$P_{CORE} = 18.31 \times 192\,216^{0.188} \times 470.5^{2.118} \times 300\,000 \times 10^{-14} = 0.248 \text{ W}$$

### Step 5.

The core losses are 0.248 W which is less than  $\frac{1}{3}$  of P<sub>HEAT</sub> (0.493 W)

### Step 6.

$$P_{CU_{allowed}} = 1.48 - 0.248 = 1.32 \text{ W}$$

### Step 7.

$$R_{OPER} = 0.0018 \times \left[ \frac{274.5 + 50}{259.5} \right] = 0.00225 \text{ } \Omega$$

$$P_{DC} = 20^2 \times 0.00225 = 0.900 \text{ W}$$

$$P_{AC} = 0.00340 \times 7.39^2 \times \sqrt{300\,000} \times 0.00225 = 0.229 \text{ W}$$

### Step 8.

$$P_{TOTAL} = 0.248 + 0.900 + 0.229 = 1.377 \text{ W}$$

### Step 9.

$$\Delta T = 1.377 \times 26.96 = 37.12 \text{ } ^\circ\text{C}$$

$$T_{OPER} = 50 + 37.12 = 87.12 \text{ } ^\circ\text{C}$$

### Step 10.

$$I_{PEAK} = 20 + \frac{7.39}{2} = 23.7 \text{ A}$$

I<sub>SAT</sub> = 49 A which is greater than the required 23.7 A

## IHLP Selection Example

### SELECTION CRITERIA

1. Limit core losses ( $P_{CORE}$ ) to  $\leq 1/3$  of total losses for 40 °C temperature rise ( $P_{HEAT}$ ).
2. Total copper losses allowed will be equal to  $P_{HEAT} - P_{CORE}$ .
3. Maximum component temperature should be kept  $\leq 125$  °C.
4. Maximum  $\Delta T$  should be  $\leq 40$  °C (this can be exceeded provided caution is taken to insure max. temperature  $\leq 125$  °C).
5.  $I_{PEAK} \leq I_{SAT}$  (recommended,  $I_{PEAK}$  can exceed  $I_{SAT}$  with caution due to soft saturation of IHLP product).

### GOVERNING EQUATIONS

1.  $B_{PK_{OPER}} = \frac{ET_{ckt}}{ET_{100}} \times 100$  [G]
2.  $f_e = \frac{f_0}{2\pi(\delta - \delta^2)}$  [Hz]
3.  $P_{CORE} = K_0 f_e^{K_f - 1} B_{pk}^{K_b} \times f_0 \times 10^{-14}$  [W]
4.  $P_{AC} = K_1 \times \Delta I^2 \times \sqrt{f_0} \times R_{OPER}$  [W]
5.  $R_{OPER} = R_{MAX} \times \left[ \frac{274.5 + T_{AMB}}{259.5} \right]$  [A]
6.  $P_{DC} = I_{DC}^2 \times R_{OPER}$  [W]
7.  $P_{TOTAL} = P_{CORE} + P_{DC} + P_{AC}$  [W]
8.  $\Delta T = P_{TOTAL} \times R_{TH}$  [°C]
9.  $T_{OPER} = T_{AMB} + \Delta T$  [°C]
10.  $I_{PEAK} = I_{DC} + \frac{\Delta I}{2}$  [A]

### Notes

- (1) Use equation #3 for -01 and -11 components
- (2) Equation #7 assumes a 40 °C temperature rise and will have the same units as  $R_{MAX}$ .
- (3) For equations #3  $f$  in Hz and  $B_{PK}$  in G
- (4)  $R_{OPER}$  is based on a 40 °C temperature rise
- (5)  $K_f$  is 1.188 for -01 material and 1.173 for -11 material
- (6)  $K_b$  is 2.118 for -01 material and 2.213 for -11 material

### SELECTION PROCESS

#### Note

- This process assumes that the following is known: Required inductance, frequency,  $I_{DC}$ ,  $\Delta I$ ,  $T_{AMB}$ , and  $V\text{-}\mu\text{s}$  (ET) required

- |  |   |
|--|---|
| <p><b>Step 1.</b> Select inductor value based on controller data sheet recommendation and current (<math>I_{DC}</math>) rating.</p> <p><b>Step 2.</b> Determine peak operational flux density in Gauss using equation #1.</p> <p><b>Step 3.</b> Calculate effective frequency using equation #2.</p> <p><b>Step 4.</b> Determine core loss using equation #3 (see notes #1 and #2) and compare to selection criteria #1.</p> <p><b>Step 5.</b> If core losses are <math>&gt; 1/3 P_{HEAT}</math> select a larger inductor.</p> | <p><b>Step 6.</b> Use selection criteria #2 to determine allowable copper losses.</p> <p><b>Step 7.</b> Determine actual copper losses using equations #4, #5 and #6.</p> <p><b>Step 8.</b> Use equation #7 for total losses.</p> <p><b>Step 9.</b> Determine <math>\Delta T</math> using equation #8 and insure <math>T_{OPER} \leq 125</math> °C using equation #9.</p> <p><b>Step 10.</b> Verify <math>I_{PEAK}</math> is less then <math>I_{SAT}</math> using equation #10 for the selected part (see selection criteria #5).</p> |
|--|---|

### DEFINITIONS

- |   |   |
|---|---|
| $ET_{ckt}$ V- $\mu\text{s}$ product of the circuit                      | $f_0$ Switching frequency in Hz                 |
| $ET_{100}$ V- $\mu\text{s}$ product at 100 Gauss from table #1          | $R_{TH}$ Thermal gradient of IHLP from Table #1 |
| $P_{CORE}$ Core losses in W   | $f_e$ Effective frequency in Hz                 |
| $P_{DC}$ Losses due to the $D_{CR}$ of the inductor copper winding in W | $\delta$ Duty cycle                             |
| $K_0$ IHLP core constant from table #1                                  | $P_{AC}$ Losses in the coil due to AC effects   |
|   | $K_1$ AC loss constant from Table #1            |